T470V137 Included device families

Aug 26, 2025

This manual covers the display devices supported by the T470 system.

Devices are covered in alphabetical order of manufacturer, with projectors first, followed by flat panels. The numbers after the names are the codes using to select that family in Setup on a PC.

PhantomAbsVol ; 0000
PhantomIncVol ; 0010
PhantomAbsBlankMute ; 0020
PhantomToggleBlankMute ; 0030

----------projectors first----------

Acer_1 ; 0400

BenQBase ; 1000
BenQBase9600 ; 1005
BenQNoCR ; 1200

Canon ASCII ; 1400

CasioProj1 ; 1600

Dell ; 1800

EIKI/Sanyo Base ; 1C00

Epson VP21 Two VGA Net53 ; 2000
Epson VP21 Two VGA Net50 ; 2010
Epson VP21 VGA/BNC Net53 ; 2020
Epson VP21 3 x HDMI ; 2025
Epson VP21 VGA/BNC Net50 ; 2030
EpsonVP21_2VGA_Mirror_Net53 ; 2040
EpsonVP21_2VGA_Focus_Net53 : 2050

Epson IR 1, Common Power On/Off ; 2080
Epson IR 2, Sep. Power On/Off ; 2090

EVision ; 2100

Hitachi Single Audio ; 2400
Hitachi Individual Audio ; 2410
HitachiBenQBase ; 2450

InFocus Base 9600 ; 2600

Mimio Projector ; 2A00

Mitsubishi Proj (Vol 21 ; 2B00
Mitsubishi Proj (Vol 21) Slow ; 2B01
Mitsubishi Proj (Vol 21) LED ; 2B02

Mitsubishi Proj (Vol 31) ; 2B10
Mitsubishi Proj (Vol 31) Slow ; 2B11

Mitsubishi Proj (Vol 32) ; 2B20
Mitsubishi Proj (Vol 32) Slow ; 2B21

Mitsubishi Proj (Vol 60) ; 2B30
Mitsubishi Proj (Vol 60) Slow ; 2B31

Mitsubishi Proj (Vol 100) ; 2B40
Mitsubishi Proj (Vol 100) Slow ; 2B41

Mitsubishi Proj (Vol 10) ; 2B50
Mitsubishi Proj (Vol 10) Slow ; 2B51

Mitsubishi Proj IncDec ; 2B60

Mitsubishi Proj IncDec by 3s ; 2B61

NEC 38400, Vol 63 ; 2C00
NEC 38400, Vol 31 ; 2C01
NEC 38400, Vol 32 ; 2C02
NEC38400_NewHDMI_32 ; 2C03
NEC 19200, Vol 63 ; 2C10
NEC 9600, Vol 63 ; 2C20
NEC 4800, Vol 63 ; 2C30

NEC_IR_1 ; 2C70

Optoma 1/2, Vol 0->10 ; 2C80
Optoma 1/0, Vol 0->10 ; 2C81
Optoma 1/2, Vol 0->15 ; 2C82
Optoma 1/0, Vol 0->15 ; 2C83
Optoma 1/2, Vol 0->20 ; 2C84
Optoma 1/0, Vol 0->20 ; 2C85
Optoma_1_2_Vol_10_2 ; 2C86

Optoma_1_0_Vol_30 ; 2C87

Panasonic OSH:0/1 ; 3000
Panasonic_OSH_0_1_19200 ; 3001
Panasonic OSH/HD1 ; 3010
Panasonic_OSH_HD1_19200 ; 3011
Panasonic OSH/OSH ; 3020
Panasonic_OSH_OSH_19200 ; 3021
Panasonic_OSH_OSH_IncVol_9600 ; 3030
Panasonic_OSH_OSH_IncVol_19200 ; 3031

Panasonic Adr OSH:0/1 ; 3100
Panasonic_Adr_OSH_0_1_19200 ; 3101
Panasonic_Adr_OSH_0_1_DP1 ; 3105
Panasonic Adr OSH/HD1 ; 3110
Panasonic_Adr_OSH_HD1_19200 ; 3111
Panasonic Adr OSH/OSH ; 3120
Panasonic_Adr_OSH_OSH_19200 ; 3121

Sharp proj. 1 ; 3C00

Sony A9 Proj 8E1 ; 4000
Sony A9 Proj 8N1 ; 4010
Sony ADCP 1 Proj 8E1 ; 4020
SonyIR1 ; 4040

Viewsonic_1 ; 4400

VivitekD1 ; 5C00

----------Flat panels (LCD) ----------

AHA_LCD_1_Sources ; 6100
AHA_LCD_1_Arrows ; 6110

A2T_LCD ; 6115

BenQ_LCD1 ; 6200
BenQ_LCD2 ; 6210
BenQ_LCD2_VolTwice ; 6218
BenQ_LCD3 ; 6219
BenQ_LCD4 ; 6220
BenQ_LCD5 ; 6221

BlueSquareLabs_LCD ; 6250
BlueSquareLabs_LCD2 ; 6251

CommBox_LCD_IR ; 6400
CommBox_LCD_Direct_Res ; 6410
CommBox_LCD_Direct_RL2 ; 6420
CommBox_LCD_RS232_FHD_1_2 ; 6430
CommBox_LCD_RS232_4K_1_2 ; 6440
CommBox_LCD_RS232_4K_1_3 ; 6450
CommBox_LCD_RS232_V4 ; 6451
CommBox_LCD_RS232_V2 ; 6452
CommBox_LCD_MR ; 6453

Dell LCD1 ; 6500
Dell LCD 2 for C8618/C5518 ; 6501

eBoard_H_LCD_1 ; 6700
eBoard_H_LCD_1_VolTwice ; 6708

Englaon_LCD ; 6750

Hisense LCD 1, NEC ; 6A00
Hisense LCD 2, RC5 ; 6A10
Hisense_LCD_3 ; 6A11

Hitachi_LCD_1_Sources ; 6C00
Hitachi_LCD_2 ; 6C10
Hitachi_LCD_3 ; 6C11

LG_xb90_91_92_93 ; 7000
LG_xb70_80_90_A0 ; 7010
LG_IR1 ; 7015
LG_IR2 ; 7016

MitsubishiLCD ; 7400

NECMulteos ; 7800
NEC_E_Series ; 7810

Newline_I_Series ; 7850
Newline_NT ; 7851

Orion_LCD1 ; 7900

PanasonicLCD ; 7C00
PanasonicLCD2 ; 7C01

PhilipsBDLLCD1_6 ; 8000
PhilipsBDLLCD1_86 ; 8020
PhilipsBDLLCD1_87 ; 8028
PhilipsBDLLCD1_88 ; 8030
PhilipsBDLLCD1_92 ; 8040
PhilipsBDLLCDwall ; 8041
PhilipsBDLLCD2 ; 8100

Philips SerialXpress series LCD Inc Vol ; 8120
Philips SerialXpress series LCD Abs Vol ; 8130

PhilipsLCD_IR_1 ; 8200
PhilipsLCD_IR_3 ; 8210

PrometheanLCD1 ; 8400
PrometheanLCD2 ; 8410
PrometheanLCD3 ; 8411

Samsung LCD, Plasma 1, AA cmds RS232 ; 8800
Samsung LCD, 68 cmds RS232 ; 8840

Samsung LCD IR 1, Com. Pwr. On/Off ; 8900
Samsung LCD IR 2, Sep. Pwr. On/Off ; 8910
Samsung LCD IR 3, Com. Pwr. On/Off ; 8920
Samsung LCD IR 4, Sep. Pwr. On/Off ; 8930

SharpLCD100_HDMI1_4_PC8 ; 8C00
SharpLCD100_HDMI1_4_PC7 ; 8C10
SharpLCD100_HDMI1_3_PC6 ; 8C20
SharpLCD60_HDMI4_7_PC8 ; 8D00
SharpLCD60_HDMI1_3_PC7 ; 8D10
SharpLCD60_HDMI4_6_PC7 ; 8D20
SharpLCD60_HDMI4_6_PC3 ; 8D30
SharpLCD60_HDMI4_NoPC ; 8D40

SharpLCDLAN ; 8E00
SharpLCD38400_V1 ; 8E10

SoniqLCD_IR_1 ; 9000
SoniqLCD_RS232_1 ; 9040

SmartLCD1 ; 9200

SonyBraviaLCD ; 9400
SonyTVIR1 ; 9410
SonyTVIR2 ; 9411

TCL IR1 ; 9450
TCL IR2 ; 9451

Touchboard_115k ; 9500

Donview ; 9501
Donview2 ; 9502

TouchboardPro ; 9505

TwoTOUCH_CTOUCH ; 9800

Viewsonic_LCD1 ; A000
Viewsonic_LCD2 ; A010
Viewsonic_LCD3 ; A020
Viewsonic_LCD4 ; A030

---------- Switchers/Amps/Other ----------

Altronics_1 ; C790

Aurora_LD2625 ; C795

Audac_MTX48 ; C797

Atlona_SW ; C800

AVGear ; C805

Bluestream_CMX42 ; C810
Bluestream_MFP_72 ; C811
Bluestream_IR1 ; C812

CleanDig_WUH4A ; C815
CleanDig_MUH44 ; C816

Huddlecam ; C850

Kramer_VP778_SW ; C900
Kramer_VP440H2 ; C901
Kramer_VP440X ; C902

Yamaha_YNCA ; C950

ZonePro ; C960

See Part C manual for IR and Aux RS232 included devices